



Foam Carrier Plate

The UniGripper foam carrier plate ensures the most convenient and effective way to change suction foam on the market. The foam carrier plate is attached to the rest of the UniGripper with screws and can be removed just by loosening these. The foam carrier plate can then be placed upside down in an ergonomical position for the foam to be changed. As the foam carrier plate can be separated from the UniGripper, the rest of the UniGripper and the connection to the robot can be left untouched. Furthermore, if an extra foam carrier plate is available, replacing the plates can be made in minutes and maintenance downtime is minimized: The Unigripper can continue in operation and the foam replacement can be carried out months or years later, when a new foam is needed.

